

Excel Intelligent PDU Part Number Structure

Management Level

INT1 = Local and remote overall powering

INT3 = Local and remote overall and per socket monitoring and individual outlet switching

Special requests

INT2 = Local and remote overall and per socket monitoring

Outlets: quantity and type

Most Common types

C13 = 10A

C19 = 16A

SCH = Schuko

UKL = UK 13A Left*

UKR = UK 13A Right*

Special requests

C13L = 13A Locking

C19L = 16A Locking

Length of lead
and (**T**op or (**B**)ottom
– (just length for
Horizontal)

1

2

3

4

5

6

555-1V-Com16-INT1-12C13-4C19-3T

Phase and Orientation

1V = Single Phase Vertical

3V = 3 Phase Vertical

1H = Single Phase Horizontal

3H = 3 Phase Horizontal

555-500-100 Temperature Sensor Kit

555-500-200 Humidity Sensor

555-500-800 Door Sensor KIT

Input & Power

Most Common types

Com16 = 16A (Commando)

Com32 = 32A (Commando)

Special requests

C14 = 10A

C20 = 16A

UK = 13A

Qty in
multiples
of 4

2nd outlet option,
if a 3rd and a 4th required,
just insert additional requirements
as before

*Selecting Right - this it will mean the Earth Pin on the 3 pin plug is to the Right and the lead will be to the left, and if you choose Left the pin will be to the left and the lead will be to the right